


# OPTONICA

USER MANUAL

SKU: 9042

## LED Flame Lamp 5W SMD Bronze Colour With Battery



### Assembling the Lamp

1. Open the box and protective packaging of the lantern lamp and bulb. Carefully unwrap all parts of you lamp and inspect the lamp body and chimney condition, making sure there are no cracks, chips, or other conditions which would make the lamp unfit for use.
2. Make sure to turn the power off and unplug the power cord before installation and disassembly.
3. Press the chimney controller lever to the bottom, in order to lean the bulb base to one side. Screw up the lamp bulb, then insert the chimney and release the controller key.
4. One hand Hold tight the chimney, another hand lift the ventilator cap. Adjust the chimney glass in right position and then slowly release the cap.
5. This lamp is working by the battery, so  
**PLEASE USE THE USB OR CORRECT CHARGER**

to charge the battery until it is full charging, Then lay it on the table or hang it on the wall with the handle. OK now enjoy the memories of childhood it recalls.

### Maintenance

Proper Maintenance is the key to longevity and proper operation of the lantern lamp.

1. Using condition – Beware of electricity, can not use in wet condition.
2. If the bulb could not turn on or abnormal flicker occur, please check and make sure all connections are tight.
3. Chimney glass is fragile, so be careful while move and clean it. Please keep it out of touch of child. If accidentally broken occur, make sure to pick all the glass fragments up and treat them well. Re-purchase the appropriate frosted glass chimney.
4. Bulbs – Do not exceed the recommended Voltage. Use only E27 base bulbs.