



## LED LINEAR INDUSTRIAL LIGHT

**USER MANUAL SKU: 8251-8258** 

## **WARNING**

- 1. Before installation, ensure that the power supply is turned off and read all instructions below, and users should prepare necessary accessories and spare parts (not provided).
- 2. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- 3. The luminaire should be positioned so that prolonged staring into the luminaire at a distance closer than 0.3 m is not expected.
- 4. To reduce the risk of strangulation the flexible wiring connected to this luminaire shall be effectively fixed to the wall if the wiring is within arm's reach.
- 5. This product is not suitable for the following situations:
- 1). Working at temperatures close to or even exceeding the upper or lower limits for extended periods of time;
- 2).24 hours of continuous working;
- 3). The input voltage operates above or below the rated voltage range;
- The above situation will reduce the lifespan of the lamp and cannot meet the warranty requirements.
- 6. When installing lamps on outdoor high poles or other outdoor high place, it is recommended to add SPD at the input end to increase the product's resistance to lightning surge impact.







This product should be disposed of responsibly at the end of its life. Please recycle where facilities exist.

(Waste Electriacal ane Eceltronic Equipment Directive)